


Recommended cleaning and disinfecting guidelines

for your radios, body-worn cameras and accessories



In response to the coronavirus (COVID-19) pandemic, here are some guidelines how to keep your radios, body-worn cameras and accessories cleaned and disinfected.

General Cleaning:

- Apply 0.5% detergent-water solution with a cloth, then use a stiff, non-metallic, short-bristled brush to work all loose dirt away from the device. Use a soft, absorbent, lintless cloth or tissue to remove the solution and dry the device.
- Make sure that no solution remains entrapped near any connectors, cracks or crevices.

Disinfecting:

- Devices may be disinfected by wiping them down with over-the-counter isopropyl alcohol (rubbing alcohol) with at least 70% alcohol concentration.
- When cleaning with isopropyl alcohol, the alcohol should never be applied directly to the device. It should be applied to a cloth, which is then used to wipe down the device.
- The effects of certain chemicals and their vapors can have detrimental effects on plastics and the metal platings.

Do not use bleach, solvents or cleaning sprays to cleanse or disinfect your device.

*Ref.: Motorola Solutions, Technical Notification,
MTN-0038-20-GL, 03-2020*

Protect yourself and others

Prevent infection



Cough or sneeze into
your sleeve



Limit physical
contact



Wash your hands frequently or
use an alcohol-based hand rub



Be diligent
with cleaning



Avoid crowds of people
and keep distance